

---

---

## RADIO/DVD PLAYER WITH DELUXE SOUND —If Equipped



The Radio/DVD player is a selectable function of the multi-featured audio system. The player unit contains DVD/CD/MP3/AM-FM Stereo radio. It also accepts portable audio player inputs and it also functions as an alarm clock.

The player is connected directly to the TV and can output sound to either the stereo speakers in the TV or to the Deluxe Sound speakers in the lounge area of the coach.

See the manufacturer's information in your InfoCase for complete feature descriptions and operating instructions.

### Provide 12V Power

The TV and Radio/DVD player operate on 12-volt DC current.

- Turn on the 12-Volt Master Power (TV) switch, located on the cabinet or wall near the Radio/DVD player.

*NOTE: When the TV is not in use, the Master Power switch should be turned off to eliminate drain on the 12-volt house battery.*



### Connect Deluxe Sound Speakers

- Press the Speaker switch to TV position to connect speakers to TV and/or DVD. The Speaker switch is located near the Radio/DVD player.



### Set TV Video Input

- Turn TV and Radio/DVD player On.
- Press the MODE button on the TV or the SOURCE button on the remote to select "INPUT 1".

- The TV screen will display the DVD player logo when the correct input is selected.



### Play DVD

- Insert a DVD "face up" into slot on lower face of the player.
- The DVD will begin to load automatically. The TV screen will typically display "Reading" or "Loading".

- The DVD may load directly to the main title/menu screen or it may begin to play previews. You may be able to skip previews if desired by pressing the "Next" button on the DVD remote until you see the main menu screen.



- When the main menu screen appears, press the "Enter" button on the remote or "Play/Pause" button on



- DVD player to begin playing the main feature. Use the arrow buttons on the DVD remote to select another feature to play .
- Volume is adjusted with the DVD remote.

## TV Sound through Deluxe Sound Speakers

When watching TV programs alone, the TV normally plays sound through its own built-in stereo speakers. If you wish to connect TV stereo sound output to the Deluxe Sound speakers for a richer sound quality, follow these steps:

1. Press the Speaker switch to TV position to connect speakers to Radio/DVD player.
2. Turn the TV On.
3. Press the AUX input selection button (located just below the display on the face of the Radio/DVD player.) This will route the TV stereo sound output through the Radio/DVD player and out to the Deluxe Sound speakers.
4. Select TV channels and adjust volume using the TV remote.

## Audio-Video System Basic Operation Guide

# View Navion

---

*NOTE: See your InfoCase for specific operating guides for audio and video components.*

